



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
43	Drive shaft washer	656	Spool spring washer	913	Cover
185	"E" washer	659	Drag plate washer	914	A strong magnet
187	"E" washer	661	Handle washer	915	Bearing cover
207	Push slice screw	665	Big ring	916	Drive gear-high speed
211	Set plate screws	666	Small ring	917	High speed pinion gear
215	Cover screw	670	Close cover screws	918	Spool shaft
384	Ball bearing (S6700)	672	Fixed plate screws	919	Spool cannulation
388	Ball bearing (S85)	673	Screw for bearing cover	920	Sound gear
392	Ball bearing (S105)	679	Washer 2	921	T handle nail
395	One-way bearing	680	Drive shaft coat washer	922	Cramp
400	Drive shaft coat	698	Spool ring	923	Close cover
401	"O" ring	767	Lock set	924	Front drag plate
404	Friction spring	768	Handle shaft coat	925	Rear drag plate
406	Set plate	769	Down button	926	Anti-reverse ratchet
418	Sound coat	770	Handle fixing cover	927	Alarm sound gear
420	Sound nail	771	Drive shield	930	Side plate screws
425	Screw embedded clip	772	Handle bolt	931	Reel foot screws
428	Sound nail spring	776	Handle arm	932	Bushing screw pronunciation
547	Drag tension knob	777	Embedded clip	933	Spool shaft screw
564	Alarm pin	779	Loose sleeve screw	934	Spool shaft spring
598	Handle bolt washer	780	Handle knob (EVA)	935	The pronunciation of shrapnel
601	Washer 1	782	Frame	936	Bearing ring
627	Drag knob cover	783	Reel foot	937	Alarm spring
630	"O" ring	784	Drag control lever	938	Drag control lever washer
631	Wrench	785	Spool	939	Slow down Niu Huasi
640	Drive shaft	786	Right plate	940	Drag plate
643	Pre-program key	792	Ball bearing (S624)	943	Handle knob screw
646	Pre-program key pin	793	Ball bearing (S694)	944	Handle lock ring
647	Set plate nail	873	Strike alert lever		
649	Pre-program plate	910	Anti-reverse dog		
651	Drag plate undersleeve	911	Lever spring		
655	Fixed plate	912	Pronunciation bushing		