



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
43	Drive shaft washer	659	Drag plate washer	910	Anti-reverse dog
185	"E" washer	661	Handle washer	911	Lever spring
187	"E" washer	665	Big ring	912	Pronunciation bushing
207	Push slice screw	666	Small ring	913	Cover
211	Set plate screws	670	Close cover screws	914	A strong magnet
215	Cover screw	672	Fixed plate screws	915	Bearing cover
384	Ball bearing (S6700)	673	Screw for bearing cover	918	Spool shaft
388	Ball bearing (S85)	679	Washer 2	919	Spool cannulation
392	Ball bearing (S105)	680	Drive shaft coat washer	920	Sound gear
395	One-way bearing	698	Spool ring	921	T handle nail
400	Drive shaft coat	766	Drive shield	922	Cramp
401	"O" ring	767	Lock set	924	Front drag plate
404	Friction spring	768	Handle shaft coat	925	Rear drag plate
406	Set plate	769	Down button	926	Anti-reverse ratchet
418	Sound coat	770	Handle fixing cover	927	Alarm sound gear
420	Sound nail	772	Handle bolt	930	Side plate screws
425	Screw embedded clip	774	Drive gear-high speed	931	Reel foot screws
428	Sound nail spring	775	High speed pinion gear	932	Bushing screw pronunciation
547	Drag tension knob	776	Handle arm	933	Spool shaft screw
564	Alarm pin	777	Embedded clip	934	Spool shaft spring
598	Handle bolt washer	778	Close cover	935	The pronunciation of shrapnel
601	Washer 1	779	Loose sleeve screw	936	Bearing ring
627	Drag knob cover	780	Handle knob (EVA)	937	Alarm spring
630	"O" ring	781	Right plate	938	Drag control lever washer
640	Drive shaft	782	Frame	939	Slow down Niu Huasi
643	Pre-program key	783	Reel foot	940	Drag plate
646	Pre-program key pin	784	Drag control lever	943	Handle knob screw
647	Set plate nail	785	Spool	944	Handle lock ring
649	Pre-program plate	792	Ball bearing (S624)		
651	Drag plate undersleeve	793	Ball bearing (S694)		
655	Fixed plate	795	Wrench		
656	Spool spring washer	873	Strike alert lever		