



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	448	Click bracket	728	Fixing lever	752	Tension knob
211	Set plate screws	449	Spring washer	730	Knob cover	753	Star drag knob
215	Cover screw	451	Handle nut washer	731	Handle bolt	754	Fixed screw
302	Star drag washer	457	Clutch dog	732	Spool shaft	767	Lock set
384	Ball bearing (S6700)	460	Drive shaft shield	733	Clutch release yoke	768	Handle shaft coat
388	Ball bearing (S85)	462	Clutch spring	734	Clutch release bar	769	Down button
389	Ball bearing (S695)	463	Cast control spring	735	Reel foot	779	Loose sleeve screw
391	One-way bearing	464	Click spring A	736	Sound spring plate	780	Handle knob (EVA)
392	Ball bearing (S105)	465	Bearingspring	737	Decorative cover	873	Strike alert lever
393	Ball bearing (S128)	467	Yoke plate	738	Close cover	912	Bushing
394	Ball bearing (S126)	468	Yoke	739	Handle arm	914	Magnet
410	Cast control screw	469	Clutch skid	740	Drive shaft	920	Sound gear
411	Cast control bracket	471	Clutch lever bracket	741	Drive gear	921	T handle nail
412	Yoke ratchet	473	Drag washer A	742	Shaft spacer	922	Cramp
435	Clutch lever screw	474	Drag washer B	743	Drive shaft bushing	927	Alarm sound gear
437	One-way bearing tube	564	Alarm pin	744	Anti-reverseratchet	932	Bushing screw
438	Anti-reversenail	601	Washer 1	745	Drive shaft washer	935	Clip
440	Spool shaft nail	631	Wrench	746	Right plate	937	Alarm spring
443	Eared washer	668	Side plate screws	747	Frame	939	Slow down washer
444	Key washer A	670	Close cover screws	748	Spool	943	Handle knob screw
445	Key washer B	679	Washer 2	749	Transitional board	944	Handle lock ring
446	Anti-reverse dog	726	Release bar	750	Lever wind washer	1021	Yoke spring
447	Anti-reverse plate	727	Side part for Release bar	751	Pinion gear		