



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	451	Handle nut washer	739	Handle arm	939	Slow down washer
211	Set plate screws	460	Drive shaft shield	742	Shaft spacer	943	Handle knob screw
215	Cover screw	463	Cast control spring	743	Drive shaft bushing	944	Handle lock ring
302	Star drag washer	464	Click spring A	744	Anti-reverseratchet	1018	Close cover
384	Ball bearing (S6700)	465	Bearing spring	745	Drive shaft washer	1019	Drive shaft
388	Ball bearing (S85)	471	Clutch lever bracket	748	Spool	1020	Clutch spring
389	Ball bearing (S695)	473	Drag washer A	750	Lever wind washer	1021	Yoke spring
391	One-way bearing	474	Drag washer B	754	Fixed screw	1022	Right plate
392	Ball bearing (S105)	564	Alarm pin	767	Lock set	1023	Frame
393	Ball bearing (S128)	601	Washer 1	768	Handle shaft coat	1024	Transitional board
394	Ball bearing (S126)	631	Wrench	769	Down button	1025	Cast control screw
411	Cast control bracket	668	Side plate screws	779	Loose sleeve screw	1026	Tension knob
435	Clutch lever screw	670	Close cover screws	780	Handle knob (EVA)	1027	Star drag knob
437	One-way bearing tube	679	Washer 2	873	Strike alert lever	1028	Yoke ratchet
438	Anti-reverserail	726	Release bar	912	Bushing	1029	Pinion gear
440	Spool shaft nail	727	Side part for Release bar	914	Magnet	1030	Drive gear
443	Eared washer	728	Fixing lever	920	Sound gear	1031	Clutch release bar
444	Key washer A	730	Knob cover	921	T handle nail	1032	Clutch release yoke
445	Key washer B	731	Handle bolt	922	Cramp	1033	Clutch dog
446	Anti-reverse dog	732	Spool shaft	927	Alarm sound gear	1034	Yoke plate
447	Anti-reverse plate	735	Reel foot	932	Bushing screw	1035	Yoke
448	Click bracket	736	Sound spring plate	935	Clip	1036	Clutch skid
449	Spring washer	737	Decorative cover	937	Alarm spring		