



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
1	Right plate	395	One-way bearing	645	Strike alert lever
2	Frame	400	Drive shaft coat	646	Pre-program key pin
3	Embedded clip	401	"O" ring	647	Set plate nail
5	Close cover	402	Shaft coat	648	Spool shaft
7	Pre-program plate	418	Sound coat	650	Handle bolt
8	Pre-program key	420	Sound nail	653	Fixed screws
10	Handle shaft retainer	425	Screw embedded clip	655	Fixed plate
14	Handle shaft coat	427	Stopping stop spring	657	Alarm sound gear
16	Washer 3	428	Sound nail spring	659	Drag plate washer
17	Washer 2	452	Reel foot screws	660	Bearing ring
20	Anti-reverse ratchet	548	Drive shield	661	Handle washer
21	Drag tension knob	551	Drag control lever	664	Spool spring washer
34	Spool spring washer	554	Handle arm	666	Small ring
40	Spool shaft spring	581	T handle nail	667	Anti-reverse dog
43	Drive shaft washer	598	Handle bolt washer	669	Side plate screws
165	Fixed nuts	601	Washer 3	670	Close cover screws
185	"E" washer	602	Handle knob screw 2	671	Spool shaft screw
187	"E" washer	627	Drag knob cover	672	Fixed plate screws
191	Set plate	628	Spool cannulation	673	Screw for bearing cover
202	Handle knob screw 1	629	Handle knob	674	Anti-loose screw
207	Push slice screw	630	"O" ring	677	Drag control lever washer
211	Set plate screws	631	Wrench	679	Washer 1
214	Alert ratchet screws	634	Spool	680	Drive shaft coat washer
215	Cover screw	637	Reel foot	681	Alert ratchet
233	Rod clamp	638	Drive gear-high speed	682	Cover
379	Ball bearing (S117)	640	Drive shaft	684	Drag plate
380	Ball bearing (S605)	641	Bearing cover	698	Spool ring
384	Ball bearing (S6700)	642	Front drag plate		
389	Ball bearing (S695)	644	High speed pinion gear		