



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
4	Set plate	419	Pre-program key pin	666	Small ring
10	Handle shaft retainer	420	Sound nail	667	Anti-reverse dog
12	Right plate	421	Bearing cover	668	Side plate screws
13	Frame	422	Spool spring washer	670	Close cover screws
14	Handle shaft coat	423	Drag plate washer	672	Fixed plate screws
17	Washer 2	424	Spool shaft screw	674	Anti-loose screw
18	Close cover	425	Screw embedded clip	679	Washer 1
19	Embedded clip	426	Screw for bearing cover	681	Alert ratchet
66	Spring spool washer	427	Stopping slock spring	698	Spool ring
178	Set plate nail	428	Sound nail spring	818	Spool
185	"E" washer	429	Bearing ring	819	Drag control lever
195	Rod clamp	430	Drag control lever washer	820	Spool cannulation
202	Handle knob screw 1	431	"O" ring	821	Front drag plate
207	Push slice screw	452	Reel foot screws	825	Cover
211	Set plate screws	500	Reel foot	826	Drag plate
214	Alert ratchet screws	503	Fixed screws	827	Spool shaft
215	Cover screw	546	Drive shaft washer	828	Drive gear-high speed
379	Ball bearing (S117)	581	T handle nail	831	Drive shaft coat
381	Ball bearing (S606)	598	Handle bolt washer	832	Drive shield
384	Ball bearing (S6700)	601	Washer 3	854	Drag tension knob
390	Ball bearing (S696)	602	Handle knob screw 2	863	High speed pinion gear
395	One-way bearing	604	Spool shaft spring	873	Strike alert lever
397	Drive shaft	629	Handle knob	874	Shaft coat
398	Pre-program plate	630	"O" ring	875	Pre-program key
399	Pinion gear cover	631	Wrench	878	Anti-reverse ratchet
416	"E" washer	650	Handle bolt	879	Handle arm
417	Drag knob cover	655	Fixed plate	885	Handle washer
418	Sound coat	657	Alarm sound gear	889	Drive shaft coat washer