



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	262	Pre-program key	308	Push slice screw
67	Push slice	263	Fixed nuts- L	309	Piston screw
68	Alarm lever knob	264	Fixed nuts	311	Alarm spring
95	Limited nail	265	Drive shield	3312	Shaft insert spring
110	Push button spring	266	Drive shaft washer	313	Drive shaft spring
112	Limited spring	267	Drive shaft cover	314	Stopping block spring
146	Alarm lever cap	269	Plate support	315	Spool shaft spring
148	Alarm lever slice	270	Harness lugs	316	Sound nail spring
153	Button base	271	Piston sealing washer	317	Alarm hammer
154	Handle shaft coat	273	Lever hub cover	318	Dragcontrol lever thrust ring
166	Fixed plate screw	274	Push button shaft	319	Dial washer
169	Fixed nail	275	Handle bolt	320	Alarm limited coat
173	Limited bushing	276	Handle arm	321	Alarm lever base
176	Alarm crosspin support	277	Crosspin support	322	Various speed washer
182	Spool nail	278	Alarm crosspin support	323	Gear washer
184	Stopping slice	279	Drive shaft	324	Rubber ring
187	"E" washer	280	Stopping bracket pin	325	Piston big ring
202	Handle knob screw	281	Reel foot screws	326	Piston small washer
206	Retainer screw	283	Gear shaft pin	327	Sound slice
208	Crosspin fixed screw	284	Pre-program key pin	329	Spool shaft
209	Alarm lever screw	285	Eccentric	332	Drag tension knob
214	Push slice screw	286	Sound nail	333	Rod clamp
218	Alarm lever spring	287	Fixed screw	334	Drag control lever
223	Drag control lever washer(B)	288	"E" washer	335	Right side cover
224	Pre-program plate washer	289	Thrust washer	336	Left side plate
225	Spacer	291	Drive gear-low speed	337	Drag lever arm
227	Drag lever washer	293	Slide knob	338	Frame
234	Drag washer	294	"E" washer	370	Wrench B
236	Alarm support	296	Stopping bracket	527	T handle nail
239	Drag control lever cap	297	Anti reverse dog	529	Handle shaft coat washer
245	Spool	298	Reel foot	556	Ball bearing
250	Anti-reverse ratchet	299	Friction washer	717	Handle shaft fixed screw
251	Pressure plate	300	Alarm sound slice	721	Drive gear-high speed
255	Handle knob	301	Spool spring washer	722	High speed pinion gear
257	Slide coat	302	Spool washer	723	Wrench A
258	Drive shaft screw	303	Low speed pinion gear		
259	Piston cover	305	Side plate screws		
260	Piston button	306	Shaft screw		
261	Pre-program screw	307	Stopping bracket screw		