



No.	PARTS NAMES	No.	PARTS NAMES	No.	PARTS NAMES
10	Handle shaft retainer	286	Sound nail	345	Rod clamp
67	Push slice	288	"E" washer	346	Cooling shield
68	Alarm lever knob	289	Thrust washer	347	Limited cover screw
110	Push button spring	290	Drive gear-high speed	348	Strike alert shaft
153	Button basement	291	Drive gear-low speed	349	Strike alert nail
154	Handle shaft coat	293	Slide knob	350	Holder nut
169	Fixed nail	294	"E" washer	351	Drive shaft cover
176	Alarm lever crosspinsuffort	295	Stopping bracket screw	352	Drag control lever cap
182	Spool nail	296	Stopping bracket	353	Drag control lever
184	Stopping slice	297	Anti reverse dog	354	Limited cover
187	"E" washer	300	Alarm sound slice	355	Strike alert lever
202	Handle knob screw	301	Spool spring washer	356	Drag control lever
206	Retainer screw	302	Spool washer	357	Lever hub cover
209	Alarm lever screw	303	Pinion gear	358	Fixed nuts
214	Push slice screw	304	High speed pinion gear	359	Shaft nail
215	Cover screw	305	Side plate screws	360	Eccentric
224	Pre-program plate washer	308	Spool drag screw	361	Spacer
227	Drag control lever washer	309	Piston screw	362	Reel foot
250	Anti-reverse ratchet	311	Alarm spring	363	Spool washer
257	Slide coat	312	Shaft insert spring	364	Strike alert shaft screw
258	Drive shaft screw	313	Drive shaft spring	365	Alarm crosspin suffort
259	Piston cover	314	Stoppingblock spring	366	Brake spring
260	Piston button	315	Spool shaft spring	367	Strike stop
261	Pre-program screw	316	Sound nail spring	368	Alarm hammer
262	Pre-program key	318	Dragcontrol lever thrust ring	369	Drag washer
264	Fixed nuts	319	Dial washer	371	Alarm limited coat
265	Drive shield	321	Alarmsupport	372	Right side plate
266	Drive shaft washer	322	Various speed washer	373	Limited button
269	Plate support	323	Friction washer	527	T handle nail
270	Harness lugs	324	Rubber ring	556	Ball bearing
271	Piston sealing washer	325	Piston big ring	576	Pull buckle limit nail
274	Push button shaft	326	Piston small washer	577	Pull button
275	Handle bolt	327	Sound silce	717	Handle knob screw
276	Handle arm	329	Spool shaft	723	Wrench
278	Alarm lever crosspin suffort	332	Drag tension knob	724	Alarm socket
279	Drive shaft	340	Left side plate	725	Lever hub nail
280	Stop shaft	341	Spool	904	Fixed screw
281	Reel foot screws	342	Front plate	905	Handle knob
283	Gear shaft pin	343	Frame		
284	Pre-programkey pin	344	Pressure plate		