



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	286	Sound nail	345	Rod clamp
67	Push slice	288	"E" washer	346	Cooling shield
68	Alarm lever knob	289	Thrust washer	347	Lever hub nail
110	Push button spring	290	Drive gear-high speed	348	Strike alert knob
153	Button base	291	Drive gear-low speed	349	Strike alert nail
154	Handle shaft coat	293	Slide knob	350	Holder nut
169	Fixed nail	294	"E" washer	351	Drive shaft cover
176	Alarm lever crosspin support	296	Stopping bracket	352	Drag control lever cap
182	Spool nail	297	Anti reverse dog	353	Drag control lever
184	Stopping slice	300	Alarm sound slice	354	Limited plate
187	"E" washer	301	Spool spring washer	355	Strike alert lever
202	Handle knob screw	302	Spool washer	356	Drag control lever arm
206	Retainer screw	303	Low speed pinion gear	357	Lever hub cover
209	Alarm lever screw	304	High speed pinion gear	358	Fixed nuts-L
214	Push slice screw	305	Side plate screws	359	Shaft nail
223	Dragcontrol lever thrust ring	307	Stopping bracket screw	360	Eccentric
224	Pre-program plate washer	308	Spool drag screw	361	Spacer
227	Drag control lever washer	309	Piston screw	362	Reel foot
250	Anti-reverse ratchet	311	Alarm hammer spring	363	Friction washer
257	Slide coat	312	Shaft insert spring	364	Strike alert shaft screw
258	Drive shaft screw	313	Drive shaft spring	365	Alarm spring
259	Piston cover	314	Stopping block spring	366	Push button spring
260	Piston button	315	Spool shaft spring	367	Strike stop
261	Pre-program screw	316	Sound nail spring	368	Alarm hammer
262	Pre-program key	318	Dragcontrol lever thrust ring	369	Drag washer
264	Fixed nuts	319	Dial washer	371	Alarm limited coat
265	Drive shield	321	Alarm lever base	372	Front plate
266	Drive shaft washer	322	Various speed washer	373	Limited button
269	Plate support	323	Gear washer	527	T handle nail
270	Harness lugs	324	Rubber ring	556	Ball bearing
271	Piston sealing washer	325	Piston big ring	717	Handle shaft fixed screw
274	Push button shaft	326	Piston small washer	723	Wrench
275	Handle bolt	327	Sound slice	904	Fixed screw
276	Handle arm	329	Spool shaft	905	Handle knob
278	Alarm crosspin support	332	Drag tension knob	909	Limited cover screw
279	Drive shaft	340	Left side plate		
280	Stop shaft	341	Spool		
281	Reel foot screws	342	Right side plate		
283	Gear shaft pin	343	Frame		
284	Pre-program key pin	344	Pressure plate		