




No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
42	Reel foot	545	Fixed screws	1251	Small ring	1602	Handle shaft coat	1836	Double helix lever wind
46	Reel foot screws	546	Drive shaft washer	1319	Drive shaft	1606	Sound coat	1837	Fixed pin
48	Rod clamp	598	Handle bolt washer	1327	Drag plate	1613	Pronunciation nail	1838	Slider
104	M2.5 "E" washer	601	Washer 1	1328	Reel foot spacer	1642	Handle arm	1839	Guide claw
165	Fixed nuts	604	Spool shaft spring	1374	Handle knob screw 2	1650	Anti-reverse dog	1840	Sound gear
185	M2.5 "E" washer	630	"O" ring	1399	Screw sleeve	1706	Push rod sound nail	1841	Spool cannulation
207	Push slice screw	647	Set plate nail	1425	Rear drag plate	1707	The sound nail springs	1843	Drag plate undersleeve
211	Set plate screws	665	Big ring	1431	Fixed plate pin	1720	Drag adjustable washer	1844	Front drag plate
215	Cover screw	668	Side plate screws	1433	Pin with small teeth	1792	Locking plastic ring	1845	Transitional gear washer
381	Ball bearing (S606)	670	Close cover screws	1434	Spring cover for silence	1810	Spool spring washer	1846	Spiral cam spring
384	Ball bearing (S6700)	680	Drive shaft coat washer	1436	Anti-reverse ratchet	1811	Spool spring washer	1847	Slider Pot Spring
388	Ball bearing (S85)	698	Spool ring	1462	Drive gear for lever wind	1823	Cover	1848	Ceramic ring
390	Ball bearing (S696)	699	Set plate	1541	Ball bearing(S84)	1824	Guide claw nut	1849	Sideplate (front)
395	One-way bearing	754	Fixed screw	1542	Ball bearing (S625)	1825	Lever wind shaft	1852	Spool
396	Handle washer	772	Handle bolt	1548	Washer_0.3mm	1826	Drive shield	1853	Drag control lever
417	Drag knob cover	831	Drive shaft coat	1549	Washer_0.5mm	1827	Decorative piece	1854	High speed pinion gear
419	Pre-program key pin	921	T handle nail	1551	Lever wind bushing	1829	Wire loop	1855	Drive gear-high speed
420	Sound nail	943	Handle knob screw1	1552	Transition tooth fixing screw	1830	Sound-deadening sheath	1856	Close cover
424	Spool shaft screw	976	Friction spring	1564	Pre-program plate	1831	Transitional large gear_P1	1857	Frame
426	Screw for bearing cover	1147	Handle cover	1565	Pre-program key	1832	Transitional gear_P1	1858	Sideplate(rear)
428	Sound nail spring	1148	Hander cover	1566	Drag tension knob	1833	Transitional large gear_P2		
429	Bearing ring	1149	Main Knob	1567	Bearing cover	1834	Transitional gear_P2		
431	"O" ring	1151	Lock set	1590	Handle lock ring	1835	Spool shaft		