



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	460	Drive shaft shield	744	Anti-reverseratchet	939	Slow down washer
211	Set plate screws	463	Cast control spring	745	Drive shaft washer	943	Handle knob screw
215	Cover screw	464	Click spring A	748	Spool	944	Handle lock ring
302	Star drag washer	465	Bearingspring	750	Lever wind washer	988	Ball bearing (S74)
384	Ball bearing (S6700)	471	Clutch lever bracket	754	Fixed screw	1018	Close cover
388	Ball bearing (S85)	473	Drag washer A	759	Thimble	1019	Drive shaft
389	Ball bearing (S695)	474	Drag washer B	760	Spool shaft	1020	Clutch spring
391	One-way bearing	564	Alarm pin	761	Thimble spring	1021	Yoke spring
392	Ball bearing (S105)	601	Washer 1	767	Lock set	1022	Right plate
393	Ball bearing (S128)	631	Wrench	768	Handle shaft coat	1023	Frame
394	Ball bearing (S126)	668	Side plate screws	769	Down button	1024	Transitional board
411	Cast control bracket	670	Close cover screws	779	Loose sleeve screw	1025	Cast control screw
435	Clutch lever screw	679	Washer 2	780	Handle knob (EVA)	1026	Tension knob
437	One-way bearing tube	687	Aprons	873	Strike alert lever	1027	Star drag knob
438	Anti-reverse nail	726	Release bar	912	Bushing	1028	Yoke ratchet
440	Spool shaft nail	727	Side part for Release bar	914	Magnet	1029	Pinion gear
443	Eared washer	728	Fixing lever	920	Sound gear	1030	Drive gear
444	Key washer A	730	Knob cover	921	T handle nail	1031	Clutch release bar
445	Key washer B	731	Handle bolt	922	Cramp	1032	Clutch release yoke
446	Anti-reverse dog	735	Reel foot	927	Alarm sound gear	1033	Clutch dog
447	Anti-reverse plate	736	Sound spring plate	932	Bushing screw	1034	Yoke plate
448	Click bracket	737	Decorative cover	935	Clip	1035	Yoke
449	Spring washer	739	Handle arm	936	Bearing ring	1036	Clutch skid
451	Handle nut washer	743	Drive shaft bushing	937	Alarm spring		