



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	460	Drive shaft shield	756	Release bar	1038	Tension knob
211	Set plate screws	463	Cast control spring	758	Handle arm	1039	Star drag knob
215	Cover screw	464	Click spring A	759	Thimble	1040	Close cover
302	Star drag washer	465	Bearing spring	760	Spool shaft	1041	Pinion gear
384	Ball bearing (S6700)	473	Drag washer A	761	Thimble spring	1042	Drive gear
389	Ball bearing (S695)	474	Drag washer B	764	Spool	1099	Fixing lever
391	One-way bearing	564	Alarm pin	767	Lock set	1100	Side part for Release bar
392	Ball bearing (S105)	601	Washer 1	768	Handle shaft coat	1101	Clutch release yoke
393	Ball bearing (S128)	631	Wrench	779	Loose sleeve screw	1102	Anti-reverseratchet
394	Ball bearing (S126)	668	Side plate screws	873	Strike alert lever	1103	Clutch release bar
411	Cast control bracket	670	Close cover screws	920	Sound gear	1108	Clutch lever bracket
435	Clutch lever screw	679	Washer 2	921	T handle nail	1112	Clutch dog
437	One-way bearing tube	692	Knob cover	927	Alarm sound gear	1113	Yoke spring
438	Anti-reversenail	693	Handle knob (EVA)	932	Bushing screw	1114	Yoke plate
440	Spool shaft nail	724	Bearing washers	936	Bearing ring	1115	Clutch skid
443	Eared washer	731	Handle bolt	937	Alarm spring	1116	Right plate
444	Key washer A	735	Reel foot	943	Handle knob screw	1117	Frame
445	Key washer B	736	Sound spring plate	944	Handle lock ring	1118	Transitional board
446	Anti-reverse dog	742	Shaft spacer	1019	Drive shaft		
447	Anti-reverse plate	743	Drive shaft bushing	1020	Clutch spring		
448	Click bracket	745	Drive shaft washer	1028	Yoke ratchet		
449	Spring washer	750	Lever wind washer	1035	Yoke		
451	Handle nut washer	754	Fixed screw	1037	Cast control screw		