



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	449	Springwasher	740	Drive shaft	1021	Yoke spring
211	Set plate screws	451	Handlenut washer	741	Drive gear	1099	Fixing lever
215	Cover screw	460	Driveshaft shield	742	Shaft spacer	1100	Side part for Release bar
302	Star drag washer	463	Cast control spring	743	Drive shaft bushing	1101	Clutch release yoke
384	Ball bearing (S6700)	464	Clickspring A	745	Drive shaft washer	1102	Anti-reverseratchet
389	Ball bearing (S695)	465	Bearingspring	754	Fixed screw	1104	Clutch dog
391	One-waybearing	468	Yoke	755	Cast control screw	1105	Clutch spring
392	Ball bearing (S105)	473	Dragwasher A	757	Close cover	1106	Yoke plate
393	Ball bearing (S128)	474	Dragwasher B	758	Handle arm	1107	Clutchskid
394	Ball bearing (S126)	564	Alarm pin	759	Thimble	1108	Clutch lever bracket
411	Cast control bracket	601	Washer 1	761	Thimble spring	1109	Right plate
412	Yoke ratchet	631	Wrench	767	Lock set	1111	Transitional board
432	Pinion gear	668	Side plate screws	768	Handle shaft coat	1120	Release bar
435	Clutch lever screw	670	Close cover screws	779	Loose sleeve screw	1121	Spool shaft
437	One-waybearing tube	679	Washer 2	873	Strike alert lever	1122	Clutch release bar
438	Anti-reversenail	692	Knob cover	920	Sound gear	1123	Lever wind washer
440	Spool shaft nail	693	Handle knob (EVA)	921	T handle nail	1124	Frame
443	Eared washer	724	Bearing washers	927	Alarm sound gear	1125	Spool
444	Key washer A	725	Tension knob	932	Bushing screw		
445	Key washer B	729	Star drag knob	936	Bearing ring		
446	Anti-reverse dog	731	Handle bolt	937	Alarm spring		
447	Anti-reverse plate	735	Reel foot	943	Handle knob screw		
448	Click bracket	736	Sound spring plate	944	Handle lock ring		