



| No. | PARTS NAME           | No.  | PARTS NAME          | No.  | PARTS NAME                | No.  | PARTS NAME           |
|-----|----------------------|------|---------------------|------|---------------------------|------|----------------------|
| 185 | "E" washer           | 631  | Wrench              | 1028 | Yoke ratchet              | 1741 | Anti-reverseratchet  |
| 211 | Set plate screws     | 668  | Side plate screws   | 1033 | Clutch dog                | 1742 | Clutch release yoke  |
| 215 | Cover screw          | 670  | Close cover screws  | 1035 | Yoke                      | 1743 | Eared washer         |
| 384 | Ball bearing (S6700) | 679  | Washer 2            | 1113 | Clutchspring              | 1744 | Key washerB          |
| 389 | Ball bearing (S695)  | 692  | Knob cover          | 1114 | Yoke plate                | 1745 | Bearing Vasse        |
| 391 | One-waybearing       | 724  | Bearing washers     | 1115 | Clutchskid                | 1746 | Clutchlever bracket  |
| 392 | Ball bearing (S105)  | 725  | Tension knob        | 1120 | Release bar               | 1747 | Handle knob (EVA)    |
| 393 | Ball bearing (S128)  | 731  | Handle bolt         | 1121 | Spool shaft               | 1748 | Drag washer A        |
| 394 | Ball bearing (S126)  | 736  | Soundspring plate   | 1122 | Clutch release bar        | 1749 | Drag washer B        |
| 435 | Clutch lever screw   | 742  | Shaft spacer        | 1123 | Lever wind washer         | 1750 | Drag washer C_0.5MM  |
| 438 | Anti-reversenail     | 743  | Drive shaft bushing | 1159 | Reel foot                 | 1753 | Spool                |
| 440 | Spool shaft nail     | 745  | Drive shaft washer  | 1323 | Bushing screw             | 1755 | Cast control bracket |
| 446 | Anti-reverse dog     | 754  | Fixed screw         | 1328 | Reel foot spacer          | 1756 | Cast control screw   |
| 447 | Anti-reverse plate   | 761  | Thimble spring      | 1373 | Handle shaft coat         | 1757 | Close cover          |
| 448 | Click bracket        | 767  | Lock set            | 1589 | Strike alert lever        | 1758 | Drive shaft          |
| 449 | Spring washer        | 779  | Loose sleeve screw  | 1726 | Fixing lever              | 1759 | Brake wrench braces  |
| 451 | Handle nut washer    | 921  | T handle nail       | 1728 | Star drag knob            | 1760 | Pinion gear          |
| 460 | Driveshaft shield    | 927  | Alarm sound gear    | 1730 | Side part for Release bar | 1761 | Drive gear           |
| 463 | Cast controlspring   | 936  | Bearing ring        | 1732 | Handle arm                | 1762 | Right plate          |
| 464 | Click spring A       | 937  | Alarm spring        | 1735 | One-waybearing tube       | 1763 | Frame                |
| 465 | Bearingspring        | 943  | Handle knob screw   | 1738 | Thimble                   | 1764 | Transitional board   |
| 564 | Alarm pin            | 944  | Handle lock ring    | 1739 | Sound gear                |      |                      |
| 601 | Washer 1             | 1021 | Yoke spring         | 1740 | Key washer A              |      |                      |