



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
41	Reel foot cannulation 1	546	Drive shaft washer	804	Soundspring plate
42	Reel foot	564	Soundspring pin	831	Drive shaft coat
44	Fixed screws	586	Spring cover for silence	847	Friction ring
45	Reel foot cannulation 2	587	Front drag plate	860	Drag tension knob
46	Reel foot screws	588	Spool spring washer	873	Strike alert lever
48	Rod clamp	589	Anti-reverse ratchet	901	Pre-program key
66	Spool spring washer	590	Spool ring	910	Anti-reverse dog
165	Fixed nuts	591	Drag plate	943	Handle knob screw -- left teeth
178	Set plate nail	598	Handle bolt washer	980	T handle nail
185	"E" washer	601	The small washer	1000	Handle washer
207	Push slice screw	602	Handle knob screw	1015	Drive gear-high speed
211	Set plate screws	604	Spool shaft spring	1078	Pre-program plate
268	Limit spring	608	Limit button	1080	Bushing
381	Ball bearing (S606)	630	"O" ring	1081	Alarm sound gear
384	Ball bearing (S6700)	631	Wrench	1082	Limit button plate
390	Ball bearing (S696)	650	Handle bolt	1088	Cover
397	Drive shaft	655	Fixed plate	1089	Close cover
406	Set plate	666	Small ring	1090	Handle arm
416	"E" washer	668	Side plate screws 1	1091	Spool shaft
417	Drag knob cover	669	Side plate screws 2	1092	High speed pinion gear
419	Pre-program key pin	670	Close cover screws	1093	Spool cannulation
421	Bearing cover	672	Fixed plate screws	1094	Friction plate
424	Spool shaft screw	674	Anti-loose screw	1095	Right plate
426	Screw for bearing cover	679	Button washer	1096	Frame
429	Bearing ring	680	Drive shaft coat washer	1097	Spool
430	Drag control lever washer	690	Handle knob	1098	Drag control lever
431	"O" ring	691	Handle cover		
493	Soundspring	710	Bearing washer		
519	Sound gear	711	Harness lugs		