



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	425	Screw embedded clip	681	Alert ratchet
14	Handle shaft coat	427	Stopping stop spring	698	Spool ring
17	Washer 2	428	Sound nail spring	729	Anti-reverse ratchet
40	Spool shaft spring	546	Drive shaft washer	731	Reel foot screws
41	Reel foot cannulation 1	547	Drag tension knob	734	Drive shaft coat
42	Reel foot	581	T handle nail	735	Drive shield
44	Fixed screws	598	Handle bolt washer	736	Bearing bush
45	Reel foot cannulation 2	601	Washer 3	737	Right plate
48	Rod clamp	602	Handle knob screw 2	738	Frame
50	Handle arm	627	Drag knob cover	739	Drag control lever
165	Fixed nuts	630	"O" ring	740	Spool shaft
178	Set plate nail	631	Wrench	742	High speed pinion gear
185	"E" washer	641	Bearing cover	744	Low speed pinion gear
187	"E" washer	643	Pre-program key	745	Spool cannulation
192	Set plate	646	Pre-program key pin	746	Close cover
202	Handle knob screw 1	649	Pre-program plate	747	Front drag plate
207	Push slice screw	650	Handle bolt	748	Rear drag plate
211	Set plate screws	651	Drag plate undersleeve	753	Drive gear-high speed
214	Alert ratchet screws	656	Spool spring washer	754	Drive shaft
215	Cover screw	657	Alarm sound gear	818	Spool
256	Handle knob	659	Drag plate washer	823	Embedded clip
379	Ball bearing (S117)	660	Bearing ring	825	Cover
380	Ball bearing (S605)	665	Big ring	826	Drag plate
384	Ball bearing (S6700)	666	Small ring	889	Drive shaft coat washer
389	Ball bearing (S695)	667	Anti-reverse dog		
395	One-way bearing	668	Side plate screws		
396	Handle washer	670	Close cover screws		
401	"O" ring	671	Spool shaft screw		
415	Strike alert lever	673	Screw for bearing cover		
418	Sound coat	674	Anti-loose screw		
420	Sound nail	677	Drag control lever washer		
422	Friction ring	679	Washer 1		