



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	524	Rear drag plate	1354	Handle arm
42	Reel foot	525	Drag plate	1399	Screw sleeve
48	Rod clamp	539	Alarm sound gear	1412	Drive gear-high speed
165	Fixed nuts	545	Fixed screws	1426	Anti-reverse ratchet
178	Set plate nail	546	Drive shaft washer	1429	Drag plate washer
185	"E" washer	564	Sound spring pin	1431	Fixed plate pin
202	Handle knob screw 1	566	Spool ring	1433	Pin with small teeth
207	Push slice screw	598	Handle bolt washer	1542	Ball bearing (S625)
211	Set plate screws	601	The small washer	1555	Sound coat
215	Cover screw	604	Spool shaft spring	1556	Bearing cover
310	Spring washer	630	"O" ring	1557	Pre-program plate
364	Handle knob screw 1	665	Big ring	1558	Pre-program key
378	Ball bearing (S106)	668	Side plate screws	1559	Drag tension knob
381	Ball bearing (S606)	670	Close cover screws	1580	Drag plate undersleeve
384	Ball bearing (S6700)	679	Button washer	1586	Front drag plate
390	Ball bearing (S696)	680	Drive shaft coat washer	1658	Wire wheel pin
395	One-way bearing	714	T handle nail	1706	Sound nail
396	Handle washer	772	Handle bolt	1707	The sound nail springs
406	Set plate	804	Sound spring plate	1712	Cover
417	Drag knob cover	831	Drive shaft coat	1713	Close cover
419	Pre-program key pin	847	Friction ring	1714	High speed pinion gear
420	Sound nail	873	Strike alert lever	1715	Spool shaft
424	Spool shaft screw	910	Anti-reverse dog	1716	Silence sleeve
426	Screw for bearing cover	1144	Handle shaft coat	1717	Foot sleeve
428	Sound nail spring	1147	Knob upper covre	1718	Spool spring washer
429	Bearing ring	1148	Knob bottom covre	1719	Spring drag washer
430	Drag control lever washer	1149	Main Knob	1720	Drag adjustable washer
431	"O" ring	1151	Lock set	1721	Right plate
453	Handle knob screw 2	1251	Small ring	1722	Frame
493	Sound spring	1319	Drive shaft	1723	Drag control lever
519	Sound gear	1323	Reel foot screws	1724	Spool
520	Spool sleeve	1351	Drive shield		