



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	525	Drag plate	1354	Handle arm
42	Reel foot	539	Alarm sound gear	1399	Screw sleeve
48	Rod clamp	545	Fixed screws	1412	Drive gear-high speed
165	Fixed nuts	546	Drive shaft washer	1426	Anti-reverse ratchet
178	Set plate nail	564	Sound spring pin	1429	Drag plate washer
185	"E" washer	566	Spool ring	1431	Fixed plate pin
202	Handle knob screw 1	598	Handle bolt washer	1433	Pin with small teeth
207	Push slice screw	601	The small washer	1542	Ball bearing (S625)
211	Set plate screws	604	Spool shaft spring	1555	Sound coat
215	Cover screw	630	"O" ring	1564	Pre-program plate
310	Spring washer	665	Big ring	1565	Pre-program key
364	Handle knob screw 1	668	Side plate screws	1566	Drag tension knob
378	Ball bearing (S106)	670	Close cover screws	1567	Bearing cover
381	Ball bearing (S606)	679	Button washer	1580	Drag plate undersleeve
384	Ball bearing (S6700)	680	Drive shaft coat washer	1586	Front drag plate
390	Ball bearing (S696)	699	Set plate	1658	Wire wheel pin
395	One-way bearing	714	T handle nail	1706	Sound nail
396	Handle washer	772	Handle bolt	1707	The sound nail springs
417	Drag knob cover	804	Sound spring plate	1711	High speed pinion gear
419	Pre-program key pin	831	Drive shaft coat	1712	Cover
420	Sound nail	873	Strike alert lever	1713	Close cover
424	Spool shaft screw	910	Anti-reverse dog	1715	Spool shaft
426	Screw for bearing cover	966	Friction ring	1716	Silence sleeve
428	Sound nail spring	1144	Handle shaft coat	1717	Foot sleeve
429	Bearing ring	1147	Knob upper covre	1718	Spool spring washer
430	Drag control lever washer	1148	Knob bottom covre	1719	Spring drag washer
431	"O" ring	1149	Main Knob	1720	Drag adjustable washer
453	Handle knob screw 2	1151	Lock set	1721	Right plate
493	Sound spring	1251	Small ring	1722	Frame
519	Sound gear	1319	Drive shaft	1723	Drag control lever
520	Spool sleeve	1323	Reel foot screws	1724	Spool
524	Rear drag plate	1351	Drive shield		