



No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
10	Handle shaft retainer	493	Sound spring	1351	Drive shield
27	Rear drag plate	519	Sound gear	1352	Cover
31	Drag plate	539	Alarm sound gear	1354	Handle arm
38	Spool spring washer	545	Fixed screws	1357	Spool cannulation
42	Reel foot	546	Drive shaft washer	1362	Spool
48	Rod clamp	564	Sound spring pin	1399	Accessory screw sleeve
165	Fixed nuts	598	Handle bolt washer	1423	Spring cover for silence
178	Set plate nail	601	The small washer	1424	Drag plate undersleeve
185	"E" washer	604	Spool shaft spring	1426	Anti-reverse ratchet
202	Handle knob screw 1	630	"O" ring	1427	Front drag plate
207	Push slice screw	665	Big ring	1429	Drag plate washer
211	Set plate screws	668	Side plate screws	1430	High speed pinion gear
215	Cover screw	670	Close cover screws	1431	Fixed plate pin
310	Slingshot meson	679	Button washer	1433	Pin with small teeth
364	Handle knob screw 1	680	Drive shaft coat washer	1542	Ball bearing (S625)
378	Ball bearing (S106)	703	Spool ring	1555	Sound coat
381	Ball bearing (S606)	714	T handle nail	1556	Bearing cover
384	Ball bearing (S6700)	772	Handle bolt	1557	Pre-program plate
390	Ball bearing (S696)	804	Sound spring plate	1558	Pre-program key
395	One-way bearing	831	Drive shaft coat	1559	Drag tension knob
396	Handle washer	847	Friction ring	1568	Close cover
406	Set plate	873	Strike alert lever	1569	Drive gear-high speed
417	Drag knob cover	910	Anti-reverse dog	1570	Spool shaft
419	Pre-program key pin	1144	Handle shaft coat	1571	Right plate
420	Sound nail	1147	Knob upper covre	1572	Frame
424	Spool shaft screw	1148	Knob bottom covre	1573	Drag control lever
426	Screw for bearing cover	1149	Main Knob		
428	Sound nail spring	1151	Lock set		
429	Bearing ring	1251	Small ring		
430	Drag control lever washer	1319	Drive shaft		
431	"O" ring	1323	Reel foot screws		
453	Handle knob screw 2	1328	Reel foot cannulation 1		