




No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
27	Rear drag plate	601	The small washer	1427	Front drag plate
31	Drag plate	604	Spool shaft spring	1429	Drag plate washer
38	Spool spring washer	630	"O" ring	1431	Fixed plate pin
45	Foot sleeve	665	Big ring	1433	Pin with small teeth
178	Set plate nail	668	Side plate screws	1542	Ball bearing (S625)
185	"E" washer	670	Close cover screws	1555	Sound coat
207	Push slice screw	679	Button washer	1556	Bearing cover
211	Set plate screws	680	Drive shaft coat washer	1557	Pre-program plate
215	Cover screw	703	Spool ring	1558	Pre-program key
246	Reel foot	772	Handle bolt	1559	Drag tension knob
388	Ball bearing (S85)	804	Sound spring plate	1573	Drag control lever
381	Ball bearing (S606)	831	Drive shaft coat	1590	Handle lock ring
384	Ball bearing (S6700)	847	Friction ring	1602	Handle shaft coat
390	Ball bearing (S696)	873	Strike alert lever	1706	Sound nail
395	One-way bearing	910	Anti-reverse dog	1707	The sound nail springs
396	Handle washer	921	T handle nail	1720	Drag adjustable washer
406	Set plate	943	Handle knob screw 2	1870	Close cover
419	Drag knob cover	1147	Knob upper covre	1871	Handle arm
420	Sound nail	1148	Knob bottom covre	1872	Spool shaft
424	Spool shaft screw	1149	Main Knob	1873	High speed pinion gear
426	Screw for bearing cover	1150	Drive shield	1874	Drive gear-high speed
428	Sound nail spring	1151	Lock set	1875	Right plate
429	Bearing ring	1251	Small ring	1876	Frame
430	Drag control lever washer	1319	Drive shaft		
431	"O" ring	1323	Reel foot screws		
493	Sound spring	1352	Cover		
519	Sound gear	1368	Spool sleeve		
539	Alarm sound gear	1370	Spool		
546	Drive shaft washer	1374	Handle knob screw 1		
564	Sound spring pin	1423	Silence sleeve		
598	Handle bolt washer	1424	Drag plate undersleeve		
		1426	Anti-reverse ratchet		